

Panel Guard and S. S. Mini Installation For Mechanical (Screw Down) Attachment

www.snoshield.com

Note: These installation instructions are provided as assistance to installers. Sno Shield Inc takes NO responsibility for errors in application or omissions and cannot be held responsible for product installation.

Sno Shield Inc warrants the products themselves, not the installation. See Warranty Information.

This method is NOT recommended for snow guard installation on standing seam floating metal roofs.

- 1. Clean roof surface with isopropyl alcohol where snow guard is to be attached-ensure area is completely dry before attaching guard
- 2. Cut tip of sealant (use a high-quality, waterproofing sealant) nozzle and smear evenly across the entire base of Panel Guard ensuring to fill in all pockets of the base's waffle pattern and to have enough sealant to squeeze out along the perimeter of the guard
- 3. Place snow guard in desired location with the tip of the "triangle" shape pointing down the slope (toward the eve) of the roof and the "Y" shape facing up the roof (toward the ridge)
- 4. Insert minimum of two (2) screws with neoprene washers into starter holes located on the top-side of the snow guard's base. Screw through guard into purlin or structural support until 50% compression of washer is achieved. Ensure sealant has squeezed out around base and run a bead of sealant around fastener heads and around base in any areas that may have voids
- 5. While wearing rubber gloves, smooth adhesive around edge of base of the snow guard to create a water tight seal and clean up any excess adhesive

Important: Installer is responsible to determine the proper number, length, and size of screws needed for each specific project



Reminder: Surebond SB-190 is NOT recommended as a sealant for this application. A high-quality, waterproof sealant will create a better watertight seal.