



S.S. Mini Installation For Adhesive Attachment

www.snoshield.com

Note: These installation instructions are provided as assistance to installers. Sno Shield Inc takes NO responsibility for errors in application or omissions and cannot be held responsible for product installation.

Sno Shield Inc warrants the products themselves, not the installation. See Warranty Information.

1. **Clean roof surface with isopropyl alcohol where snow guard is to be attached-ensure area is completely dry before attaching snow guard**
2. **Cut tip of adhesive nozzle (Surebond SB-190 recommended) and smear evenly across the entire base of S.S. Mini and to have enough adhesive to squeeze out along the perimeter of the snow guard**
3. **Place snow guard in desired location with the tip of the “triangle” shape pointing down the slope (toward the eave) of the roof and the “Y” shape facing up the roof (toward the ridge)**
4. **Press down on the snow guard with enough force that the adhesive is squeezed out along the perimeter of the base ensuring that there are no air pockets. If necessary, run a bead of the adhesive around the edge of the base where there may be voids**
5. **While wearing rubber gloves, smooth adhesive around edge of base of the snow guard to create a water tight seal and clean up any excess adhesive**

Tip: On steeply pitched roofs, it may be necessary to temporarily secure the snow guards in place to prevent any sliding until the adhesive takes hold.

Note: SB-190 (90% Strength is achieved at 12-14 days at 50 degrees F or above).

Contact Sno Shield Inc for recommended snow guard placement and spacing layouts
1-888-976-6744 info@snoshield.com 208-524-7371
3968 E Sunnyside Rd, Bldg 3, Ammon, ID. 83406
www.snoshield.com