



## **S.S. Mini Installation For Peel and Stick Attachment 3M**

[www.snoshield.com](http://www.snoshield.com)

**Note:** These installation instructions are provided as assistance to installers. Sno Shield Inc takes **NO** responsibility for errors in application or omissions and cannot be held responsible for product installation.

Sno Shield Inc warrants the products themselves, not the installation. See Warranty Information.

1. **Clean roof surface with isopropyl alcohol where snow guard is to be attached-ensure area is completely dry before attaching snow guard**
2. **Peel the protective coating from the back of the snow guard and place it on the roof in the designated area, press down firmly to assure adhesion, be cautious when placing the snow guards as once they are applied they are difficult to remove**
3. **Seal around the edges of the snow guard using a quality silicone or adhesive to ensure no water penetrates the adhesive tape**
4. **While wearing rubber gloves, smooth silicone/ adhesive around edge of base of the snow guard to create a water tight seal and clean up any excess silicone / adhesive**

Contact Sno Shield Inc for recommended snow guard placement and spacing layouts

1-888-976-6744

[info@snoshield.com](mailto:info@snoshield.com)

208-524-7371

3968 E Sunnyside Rd, Bldg 3, Ammon, ID. 83406

[www.snoshield.com](http://www.snoshield.com)